

HighPoint-2008		Connect	IDE	SATA	SATA	eSATA	Infiniband	Mini SAS	
Host	Type	Port	ATA	SATA I	SAST II			SATA/SAS	
PCI-e	内 Internal	16						3540x8 IOP 256 2340 x8	
		8			3320 x8 IOP 256 2320 x4			3520 x8 IOP 256	
		4			2310 x4 2300 x1			3510 x8 IOP 256	2640 x4
		2			3120 x1 IOP 128				
	外 External	8						3522 x8 IOP 256 2522 x8 2322 x4	
		4				2314 x4 2304 x1		2314MS x4	
内/外	2 / 2				2312 x4 2302 x1				
PCI-X	内 Internal	16					2240		
		8			2220			3220 IOP 128	
		4			2210				
	内/外	4 / 4					2224		
PCI	内 Internal	4	454(8 HDD)	1640	1740				
		2	133(4 HDD) 100(4 HDD)	1520	1720				
		2				1522			
	内/外	2 / 2				1742			

BBU-03F	Battery Backup Unit (BBU-03F)		RR3540, RR3522, RR3520
Ext-MS-1M4S	External mini-SAS to 4 SATA	(SFF-8088 to 4SATA)	RR2522, RR2322, RR2314MS
Ext-MS-1MES	External mini-SAS to eSATA	(SFF-8088 to eSATA)	RR2522, RR2322, RR2314MS
Ext-MS-1MIB	External mini-SAS to Infiniband (Latch)	(SFF-8088 to SFF-8470)	RR2522, RR2322, RR2314MS
Ext-MS-1MSB	External mini-SAS to Infiniband (Screw)	(SFF-8088 to SFF-8470)	RR2522, RR2322, RR2314MS
IB-1M	Infiniband to Infiniband	(SFF-8470 to SFF-8470)	RR2240, RR2224
IB-1M4S	Infiniband to 4 SATA	(SFF-8470 to 4 SATA)	RR2240, RR2224
Int-MS-1MMS	Internal mini-SAS to mini-SAS	(SFF-8087 to SFF-8087)	RR3220, RR2340
Int-MS-1M4S	Internal mini-SAS to 4 SATA	(SFF-8087 to 4 SATA)	RR3520, RR3220, RR2340